


# onn

## QUICK START GUIDE




Product features and specifications may vary by model. Illustrations and descriptions in this guide are for reference only and may not exactly match your specific TV.

POWERED BY  
**VIZIO**

# Overview


## What's included:




**onn** POWERED BY  
**VIZIO**



TV Remote



2 x AAA Batteries  
for Remote




TV Stand



Screws

## Tools required:



Phillips  
Head  
Screwdriver




Wireless  
Router  
(needed for  
streaming)



Computer,  
Tablet, or  
Smartphone  
(needed for setup)



Internet  
Connection  
(needed for  
streaming)



Power your TV remote by inserting the included batteries carefully matching (+) and (-) indicated inside the battery compartment.

For product assistance &  
missing or replacement parts:

**WE CAN HELP**

**1-855-472-7400**

**ONLINE CHAT:**

[onntvsupport.com](https://onntvsupport.com)

Your product comes with a 2-Year Warranty  
from the date of purchase.

For warranty information, please see the  
product warranty located in the TV box.

Find more at **Walmart.com**

We recommend keeping your TV box for the duration of  
your warranty. See your product warranty for details.

# Assembly

## 1. INSTALLING THE STANDS


Using a **Phillips screwdriver**

Do not install the stands if you want to wall mount your TV. See your wall mount instructions for mount installation details.

Place the TV screen-down on a clean, flat, soft surface (e.g.: blanket) to prevent scratches or damage to the screen.

Use a Phillips screwdriver to attach each stand with the provided screws. Make sure the stand screws are fully tightened and the stands do not shift or move.

Place the TV upright on a stable, level surface.




## 2. CONNECTING DEVICES

### HDMI

connect a Blu-ray, DVD player, gaming console or other devices


#### Best Quality



### DIGITAL OPTICAL

connect an external digital audio system

#### Better Quality



### COAXIAL

connect to antenna/cable


#### Good Quality



## 2. CONNECTING DEVICES (continued)

### USB

connect for photos, music,  
movies and more



### CONNECTING TO POWER

After connecting all your devices, connect the power cord to a power outlet. The TV enters standby mode and its indicator light turns red.

# Setup

## ACTIVATION:

Have your mobile device ready for the VIZIO app download.

If you have a wireless network, have the network password ready.

The first time you turn on the TV, the on-screen instructions will guide you through each of the steps necessary to get your TV ready to watch.

## NOTE:

VIZIO doesn't charge for activation support - **beware of scams.**